

## GRAVITY HILL PARTS LIST

Lock & Key		Lock Only	
# LOCKG		# LOCK	
Key Only		Lock Barrel	
# KEYG		# LOCKASSEM	
Display Lock		Lock/Key Coin Door	
# GHRODLK		# LOCKHAPP	
Spanner Screw		#8 Spanner Bit	
# S0832053		# SNAKE08	
Front Shield		Rope Light Controller	
# GHSHIELD		# LIGCTRL2	
Rope Light		Flourescent Light	
# GHLIGROPE		# LIG18FL	
Ball Lift Assembly		Handle Bar	
# GHLIFTA		# GHHANDLE A	
Handle Grips		Marble	
# GRIPSHB		# MARBLES	
Exit Micro Switch		LED Light	
# GHBEXIT		# LIGLED	
Large Prize Motor		Small Prize Motor	
# GHMOTORA		# GHMOTORA1	

Micro Switch		Micro Switch	
# GHSWITCH		# SWIEXITGC	
Hopper		Gum Wheel	
# HOPPER		# GWCAPSTD	
GH Wire Harness		Back Hill	
# GHWIREH2		# GHMTNB	
Easy Hill		Hard Hill	
# GHMTNF		# GHMTNF1	
Medium Hill		Bottom Tray	
# GHMTNF2		# GHBTRAY	
Prize Chute		Large Prize Asy	
# GHPCHUTE		# GHLGPRZ	
Display Assembly		Ribbon Wire	
# GHDISPLAYA		# GHWIREH	
Flap Assembly		GH Flap Bracket	
# GHFLAP-A		# GHCAFBR	
Handle B. Bracket		HB Back Bracket	
# BRACHBGH		# BRKHBSTP	
GH Hex Chip		GH Bin Chip	
# GHCHIP		# GHCHIP1	

Security Door		GH Circuit Board	
SECURITY GH		# CIRBDS	
Chute Bracket		GH Spring	
# GHRSUP		# GHSPREP	
Power Cord		Tilt Switch	
# CORD143		# GHTILT	
Counter Assembly		Counter	
# GHCTRB		# COINCTR12	
Menu Buttons		Channel Cover	
# GHBUTTON-RED #GHBUTTON2-YELL		# GHMOUNTC	
GH Switch Cover		12 Volt Power Supply	
# GHSWCOV		# PS12V	
Shield Decals		Mountain Decals	
# DECAL SHLD		# DECAL GHM	
Front Decals		Top Decal	
#DECAL FT		# DECAL GHT	
Side Decal		Side Decal 1	
# DECAL GHS		# DECAL GHS1	
Coin Acceptor		Bill Acceptor	
# MECREPLA		# BILLACCP	