


Infrared Sensor Grid for Terminator Salvation

- Infrared sensors lighted
- Screws



Black Plastic Sensor Cover >

Black Plastic Sensor Cover >

The Infrared LED's are only active during gameplay.

While in game play you can use a cell phone camera to view the Infrared LED's. They will appear Blue in color and are grouped according to the grid shown on the right. They are located above and below the marquee sign behind the black plastic molding strips.

- symbol indicates a sensor lighted
- symbol indicates a screw

* If you lose one of the top sensors, the guns will not fire in that area/section of the screen

* If you lose one of the bottom sensors, the guns will fire away from that sensor.